


## Ready Light

Your SMART Board interactive whiteboard includes a Ready Light that indicates the status of your interactive whiteboard.



Color of Ready Light	Status
Not lit	The interactive whiteboard does not have power. Check the USB cable connections.
Solid green	The interactive whiteboard is successfully communicating with the SMART Board software on the computer.
Flashing green	The SMART Board interactive whiteboard is successfully communicating with the computer's USB driver.  <b>NOTE:</b> In this state, the interactive whiteboard only operates as a touch screen. For full functionality, ensure SMART Board software is installed on your computer.
Solid red	The interactive whiteboard has power, but it is not communicating with the computer. During the initial powering up or power reset, you will see the Ready Light turn red for a moment. This <i>brief</i> red illumination is normal behavior.
Flashing amber	Occurs only when you are updating firmware using SMART's Firmware Flashing Wizard. This is a normal behavior.
Solid amber	Problem state. Try resetting the interactive whiteboard by disconnecting and then reconnecting the USB cable at the interactive whiteboard end.